


INSTALLATION MANUAL

030152A, 030152B

REMOTE CONTROL

Requires 2xAAA batteries. Remove batteries if not used for a long period of time.

- ❶ LED indicator
- ❷ ON/OFF
- ❸ Mute sound
- ❹ Warm white LED
- ❺ Cool white LED
- ❻ Daylight LED
- ❼ Fan OFF
- ❽ Fan speeds: To turn fan ON 1(lowest) to 6 (highest)
- ❾ LED light ON / OFF
- ❿ LED dimmer
- ⓫ Breeze: Fan speeds automatic cycle between 1 to 6
- ⓬ Vacation mode: Switch on the light kit
5 minutes each 2 hours
- ⓭ Reverse function for winter and summer
- ⓮ Timer: Fan stops after 2h/4h/8h



NOTE: To pair a remote to a receiver turn ON the power supply to the fan and press the ON/OFF and MUTE buttons on the remote for 3 to 5 seconds. You will hear a beep.