


INSTALLATION MANUAL

030152C

REMOTE CONTROL

Requires 2xAAA batteries. Remove batteries if not used for long period of time.

- ① LED indicator
- ② ON/OFF
- ③ Mute Sound
- ④ Fan speeds: To turn fan ON 1(lowest) to 6 (highest)
- ⑤ Fan ON / OFF
- ⑥ Breeze: Fan speeds automatic cycle between 1 to 6
- ⑦ Reverse function for winter and summer
- ⑧ Timer: Fan stops after 2h/4h/8h



NOTE: To pair a remote to a receiver turn ON the power supply to the fan and press the ON/OFF and MUTE keys on the remote for 3 to 5 seconds. You will hear a beep.