
INSTALLATION MANUAL

6300



Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Maintenance and installation should only be carried out by a professional electrician.


INSTALLATION MANUAL


6300

REMOTE CONTROL

Requires 2xAAA batteries. Remove batteries if not used for long period of time.

- LED indicator
- ON/OFF
- Mute sound
- Warm white LED
- **6** Cool white LED
- 6 Daylight LED
- Fan OFF
- 3 Fan speeds: To turn fan ON 1(lowest) to 6 (highest)
- LED light ON / OFF
- LED dimmer
- Breeze: Fan speeds automatic cycle between 1 to 6
- Vacation mode: Switch on the light kit 5 minutes each 2 hours
- Reverse function for winter and summer
- Timer: Fan stops after 2h/4h/8h





- Hanger bracket
- 2 Receiver
- 3 Rod assembly
- Canopy
- **6** Canopy cover
- **6** Cover
- Remote control + holder
 - +2 mounting screws
 - +1.5V (AAA)x2 batteries
- S Fan motor / LED lightkit
- O Diffuser
- A Mounting hardware
- **B** Blade balancing kit

NOTE: When switching mains ON, light automatically turns on.

Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Maintenance and installation should only be carried out by a professional electrician.