
# **INSTALLATION MANUAL**

6310C/../V




### Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Maintenance and installation should only be carried out by a professional electrician.

## **INSTALLATION MANUAL**


### 6310C/../V



### REMOTE CONTROL

Requires 2xAAA batteries. Remove batteries if not used for long period of time.

- LED indicator
- ON/OFF
- Mute sound
- Warm white LED
- **6** Cool white LED
- 6 Daylight LED
- Fan OFF
- 3 Fan speeds: To turn fan ON 1(lowest) to 6 (highest)
- LED light ON / OFF
- LED dimmer
- Breeze: Fan speeds automatic cycle between 1 to 6
- Vacation mode: Switch on the light kit5 minutes each 2 hours
- Reverse function for winter and summer
- Timer: Fan stops after 2h/4h/8h



NOTE: To pair a remote to a receiver turn ON the power supply to the fan and press the ON/OFF and MUTE keys on the remote for 3 to 5 seconds. You will hear a beep.

### PACKAGE CONTENTS





























- Mounting bracket
- 2 Receiver
- Motor
- **4** 22W LED
- **6** Diffuser
- **6** Remote control + holder
  - +2 mounting screws
  - +1.5V (AAA)x2 batteries
- **7** Fan blades (3pcs)
- A Screws for blades
- B Mounting hardware
- Blade balancing kit

**NOTE:** When switching mains ON, light automatically turns on.

#### Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Maintenance and installation should only be carried out by a professional electrician.