

INSTALLATION MANUAL

6320/./V




DC MOTOR **32W MOTOR** **6 SPEED** **WINTER REVERSE MOTOR** **REMOTE CONTROL** **LIGHT ON/OFF SWITCH** **22W LED** **2000 LUMEN**

230V | LED 22W | DC Motor 32W | IP54 | Metal body | ABS blades | Rod mounted

- Maximum air flow rate 170m³/min
- Service value 5,3/W
- Standby power consumption 0,5W
- Fan sound power level 46dB(A)
- Maximum air velocity 2,84 m/sec.
- Max RPM 195



345mm (with 15cm Rod)



<p>1</p> <p>Install the fan blades and tighten screws.</p>	<p>2</p> <p>Fix the lamp panel on the motor.</p> <p>2a</p> <p>Install LED plate and connect cable.</p>	<p>3</p> <p>Install the hanger bracket with bracket installation kit.</p> <p>3a</p>
<p>4</p> <p>Remove the R clip from the pin. Then remove the pin from the rod.</p>	<p>5</p> <p>A Place the parts on the rod.</p> <p>B Pass wires through rod.</p>	<p>6</p> <p>A Put the rod into the motor and install the pin and R clip.</p> <p>B Tighten all the nuts and screws.</p>
<p>7</p> <p>A Hang the fan onto the ceiling bracket.</p> <p>B Lock into place.</p>	<p>8</p> <p>Place the receiver on the hanger bracket.</p>	

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Maintenance and installation should only be carried out by a professional electrician.

INSTALLATION MANUAL

6320/..V

9

Blue
Brown
Green and yellow

Connect wires.

10

1
2
3

11

Install the diffuser onto the LED plate.

REMOTE CONTROL

Requires 2xAAA batteries. Remove batteries if not used for long period of time.

1 LED indicator	8 Fan speeds: To turn fan ON 1(lowest) to 6 (highest)
2 ON/OFF	9 LED light ON / OFF
3 Mute sound	10 LED dimmer
4 Warm white LED	11 Breeze: Fan speeds automatic cycle between 1 to 6
5 Cool white LED	12 Vacation mode: Switch on the light kit 5 minutes each 2 hours
6 Daylight LED	13 Reverse function for winter and summer
7 Fan OFF	14 Timer: Fan stops after 2h/4h/8h

one

NOTE: To pair a remote to a receiver turn ON the power supply to the fan and press the ON/OFF and MUTE keys on the remote for 3 to 5 seconds. You will hear a beep.

PACKAGE CONTENTS

- 1 Hanger bracket
- 2 Receiver
- 3 Rod assembly
- 4 Canopy
- 5 Top assembly
- 6 Motor
- 7 Lamp panel & 22W LED
- 8 Remote control + holder
+2 mounting screws
+1.5V (AAA)x2 batteries
- 9 Cover
- 10 Diffuser
- 11 Fan blades (3pcs)
- A Screws for blades
- B Mounting hardware
- C Blade balancing kit

NOTE: When switching mains ON, light automatically turns on.

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Maintenance and installation should only be carried out by a professional electrician.